

MANUAL FOR THE INFRA RED HEATING PANEL

The Infrared Heating Panels are for roof mounting only. Do not allow any animal to touch the heater.

The box contains 1 x Infrared Heating Panel, 4 x ½" screws.

The Heating Panel is supplied for roof mounting only. Do not cover the Panel with any material which will prevent the free escape of heat. Do not drill holes in the heater.

The heater must be controlled with a suitable air sensing vivarium thermostat.

Ensure the animal cannot touch the heater. Avoid placing branches which would permit the animal to come into contact with the heater.

Instructions for use please follow carefully.

- Hold the heater in the chosen position, mark the four holes in the heater for screw positions and use a small drill to make pilot holes for the screws. Fully tighten all 4 screws.
- The main cable should be passed through the roof after drilling a 8 mm hole. Ensure that no loops of cable remain inside the vivarium to trap an animal.
- Cleaning the heater should not be required on a regular basis, but if needed the heater can be wiped clean with any sterilising solution sold for specific veivarium use.

One IR Heating Panel should be sufficient for most uses; however, in cold conditions or larger cages, an additional heater may be required.

The Infra red Heating Panels fully complies with the current EC safety standards.

